

<b>Thermal Fuse Cut-Off Sensors Available for In-Line Heaters</b>
Thermal Fuse, Cut-Off Sensor Temperature 72°C
Thermal Fuse, Cut-Off Sensor Temperature 77°C
Thermal Fuse, Cut-Off Sensor Temperature 84°C
Thermal Fuse, Cut-Off Sensor Temperature 93°C
Thermal Fuse, Cut-Off Sensor Temperature 98°C
Thermal Fuse, Cut-Off Sensor Temperature 104°C
Thermal Fuse, Cut-Off Sensor Temperature 109°C
Thermal Fuse, Cut-Off Sensor Temperature 117°C
Thermal Fuse, Cut-Off Sensor Temperature 121°C
Thermal Fuse, Cut-Off Sensor Temperature 128°C
Thermal Fuse, Cut-Off Sensor Temperature 141°C
Thermal Fuse, Cut-Off Sensor Temperature 152°C
Thermal Fuse, Cut-Off Sensor Temperature 167°C
Thermal Fuse, Cut-Off Sensor Temperature 184°C
Thermal Fuse, Cut-Off Sensor Temperature 192°C
Thermal Fuse, Cut-Off Sensor Temperature 216°C
Thermal Fuse, Cut-Off Sensor Temperature 228°C
Thermal Fuse, Cut-Off Sensor Temperature 240°C